













Effective Wet methods • Water must cover the entire surface of the work object that contacts the tool 1. Constant, continuous, appropriate volume of running water. Flow rates equal or exceed manufacturer recommendations/specs 2. Submersing the work object underwater 3. Water jet cutting







